

Keysight U2040 X-Series Wide Dynamic Range Power Sensors



Notices

Copyright Notice

© Keysight Technologies 2016

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies as governed by United States and international copyright laws.

Manual Part Number

U2041-90004

Edition

Edition 1, April 01, 2016

Printed in:

Printed in Malaysia

Published by:

Keysight Technologies
Bayan Lepas Free Industrial Zone,
11900 Penang, Malaysia

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Declaration of Conformity

Declarations of Conformity for this product and for other Keysight products may be downloaded from the Web. Go to <http://www.keysight.com/go/conformity>. You can then search by product number to find the latest Declaration of Conformity.

U.S. Government Rights

The Software is “commercial computer software,” as defined by Federal Acquisition Regulation (“FAR”) 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement (“DFARS”) 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at <http://www.keysight.com/find/sweula>. The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED “AS IS,” AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED, WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR OF ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT SHALL CONTROL.

Safety Information

CAUTION

A CAUTION notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

Environmental Conditions

The U2040 X-Series is designed for indoor use and in an area with low condensation. The table below shows the general environmental requirements for this instrument.






Environmental condition	Requirement
Temperature	Operating condition - 0 °C to 55 °C [For U2049XA Option TVA, this operating condition is applicable for both standard atmospheric environment and thermal vacuum environment.]
	Storage condition - -40 °C to 70 °C - -40 °C to 100 °C (for U2049XA Option TVA)
Humidity	Operating condition - Up to 95% RH at 40 °C (non-condensing)
	Storage condition - Up to 90% RH at 65 °C (non-condensing)
Altitude	Operating condition - Up to 3000 m (9840 ft)
	Storage condition - Up to 15420 m (50000 ft)

Regulatory Information

The U2040 X-Series complies with the following Electromagnetic Compatibility (EMC) compliances:

- IEC 61326-1/EN 61326-1
- Canada: ICES/NMB-001
- Australia/New Zealand: AS/NZS CISPR11

Regulatory Markings

 <p>The RCM mark is a registered trademark of the Spectrum Management Agency of Australia. This signifies compliance with the Australia EMC Framework regulations under the terms of the Radio Communication Act of 1992.</p>	 <p>The CE mark is a registered trademark of the European Community. This CE mark shows that the product complies with all the relevant European Legal Directives.</p> <p>ICES/NMB-001 indicates that this ISM device complies with the Canadian ICES-001.</p> <p>Cet appareil ISM est conforme a la norme NMB-001 du Canada.</p> <p>ISM GRP.1 Class A indicates that this is an Industrial Scientific and Medical Group 1 Class A product.</p>
 <p>This symbol indicates the time period during which no hazardous or toxic substance elements are expected to leak or deteriorate during normal use. Forty years is the expected useful life of the product.</p>	 <p>This instrument complies with the WEEE Directive (2002/96/EC) marking requirement. This affixed product label indicates that you must not discard this electrical or electronic product in domestic household waste.</p>
 <p>MSIP-REM-Kst-XXXXX XXXX</p> <p>This symbol is a South Korean Class A EMC Declaration. This is a Class A instrument suitable for professional use and in electromagnetic environment outside of the home.</p>	<p></p>

Waste Electrical and Electronic Equipment (WEEE) Directive 2002/96/EC

This instrument complies with the WEEE Directive (2002/96/EC) marking requirement. This affixed product label indicates that you must not discard this electrical or electronic product in domestic household waste.

Product category:

With reference to the equipment types in the WEEE directive Annex 1, this instrument is classified as a “Monitoring and Control Instrument” product.

The affixed product label is as shown below.



Do not dispose in domestic household waste.

To return this unwanted instrument, contact your nearest Keysight Service Center, or visit <http://about.keysight.com/en/companyinfo/environment/takeback.shtml> for more information.

Sales and Technical Support

To contact Keysight for sales and technical support, refer to the support links on the following Keysight websites:

- www.keysight.com/find/widedynamicsensor
(product-specific information and support, software and documentation updates)
- www.keysight.com/find/assist
(worldwide contact information for repair and service)

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

Table of Contents

Environmental Conditions	3
Regulatory Information	4
Regulatory Markings	4
Waste Electrical and Electronic Equipment (WEEE) Directive 2002/96/EC	5
Product category:	5
Sales and Technical Support	5
1 General Information	
Specifications and Characteristics	14
Cleaning	14
Connector care	14
2 Performance Verification	
Equipment List	16
Voltage Standing Wave Ratio (VSWR) Performance Verification	18
Procedure	19
Sensor Accuracy Performance Verification	24
Procedure	25
Zero Set Performance Verification	31
Equipment setup diagram	31
Test equipment settings	32
SCPI commands	32
Procedure	33
10 MHz Timebase Accuracy Performance Verification	34
Equipment setup diagram	34
Test equipment settings	34
Procedure	35
Rise Time Performance Verification	36
Equipment setup diagram	36

Test equipment settings	37
U2042XA/U2044XA/U2049XA SCPI commands	37
33250A/33220A function generator settings	38
N5172B signal generator settings	38
MATLAB code (<i>calculate the rise time of the captured trace using the equivalent time sampling method</i>)	39
Procedure	40
3 Repair Guide	
Troubleshooting	42
Repair	42
4 Contacting Keysight	
Introduction	44
Instrument serial number	44
Recommended calibration interval	45
Returning the U2040 X-Series for Service	46
Packaging the U2040 X-Series for shipment	46

List of Figures

Figure 2-1	Equipment setup for low power S11 verification	19
Figure 2-2	Equipment setup for high power S11 verification	21
Figure 2-3	Equipment setup for low power verification	25
Figure 2-4	Equipment setup for high power verification	28
Figure 2-5	Equipment setup for zero set verification	31
Figure 2-6	Equipment setup for 10 MHz timebase accuracy verification	34
Figure 2-7	Equipment setup for rise time verification	36
Figure 4-1	Serial number	45

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

List of Tables

Table 2-1	Equipment list for performance verification	16
Table 2-2	Maximum SWR specifications (for low power S11 verification)	20
Table 2-3	Maximum SWR specifications (for high power S11 verification)	23
Table 2-4	Calibration uncertainty specifications	27
Table 2-5	Zero set specifications	31

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

1 General Information

Specifications and Characteristics	14
Cleaning	14

This chapter provides the specifications and maintenance information of the U2040 X-Series wide dynamic range power sensors.

Specifications and Characteristics

For the characteristics and specifications of the U2040 X-Series, refer to the data sheet at <http://literature.cdn.keysight.com/litweb/pdf/5992-0040EN.pdf>.

Cleaning

Use a clean, water-dampened cloth to clean the body of the U2040 X-Series.

Connector care

A solution of pure isopropyl or ethyl alcohol can be used to clean the connector but make sure to keep in mind on its flammable nature.

CAUTION

- The RF connector beads deteriorate when contacted by hydrocarbon compounds such as acetone, trichloroethylene, carbon tetrachloride, and benzene.
 - Do not attempt to clean the connector with anything metallic such as pins or paper clips.
 - Clean the connector only at a static-free workstation. Electrostatic discharge to the center pin of the connector will render the U2040 X-Series inoperative.
-

Clean the connector face by first using a blast of compressed air. If the compressed air fails to remove contaminants, use a foam swab dipped in isopropyl or ethyl alcohol. If the swab is too big, use a round wooden toothpick wrapped in a lint-free cloth dipped in isopropyl or ethyl alcohol.

2 Performance Verification

Equipment List	16
Voltage Standing Wave Ratio (VSWR) Performance Verification	18
Sensor Accuracy Performance Verification	24
Zero Set Performance Verification	31
10 MHz Timebase Accuracy Performance Verification	34
Rise Time Performance Verification	36

This chapter contains the performance verification procedures which verify that the U2040 X-Series is operating within its published specifications.

Equipment List

The following equipment are required for performance verification:

Table 2-1 Equipment list for performance verification

Equipment	Critical specification	Recommended Keysight model
PNA microwave network analyzer	Frequency range: 10 MHz to 33 GHz or above Option 217 (only for the high power S11 verification)	N5224A or N5225A
Calibration kit	N-Type calibration kits	85054D
	3.5 mm-Type calibration kits Calibrated up to 33 GHz	85052B
Amplifier	Frequency range: 10 MHz to 2 GHz (to provide +26 dBm output power at the test port)	—
	Frequency range: 2 to 18 GHz (to provide +26 dBm output power at the test port)	—
	Frequency range: 18 to 33 GHz (to provide +20 dBm output power at the test port)	N4985A-P15
Coupler	Frequency range: 10 MHz to 33 GHz or above	5087-7760 or 5087-7793
Fixed attenuators	Frequency range: 10 MHz to 33 GHz or above (10 dB or 20 dB depending on the amplifier)	8490D
Power meter	Dual-channel power meter, compatible with the N8480 Series power sensors	N1914A or N1912A
Power sensor	Frequency range: 10 MHz to 18 GHz Power range: -35 to +20 dBm	N8481A
	Frequency range: 10 MHz to 18 GHz Power range: -15 to +35 dBm	N8481H
	Frequency range: 10 MHz to 33 GHz (Option 033) Power range: -35 to +20 dBm	N8485A

Table 2-1 Equipment list for performance verification (continued)

Equipment	Critical specification	Recommended Keysight model
Signal generator	Power range: -50 dBm to +22 dBm at 1 GHz Output resistance: 50 Ω Option 1EU (high output power)	E8257D
	–	N5172B
Power splitter	2-resistor-type power splitter, N-Type (f) Maximum frequency: 18 GHz	11667A
Directional RF coupler	Frequency range: 10 MHz to 2 GHz Impedance: 50 Ω	5086-7488 R-channel coupler or 86205A directional bridge
	Frequency range: 2 GHz to 33 GHz Impedance: 50 Ω	5087-7760 coupler, 50 MHz to 50 GHz
Function generator	>10 MHz pulse signal frequency Adjustable edge time of 20 ns to 100 ns	33250A
Frequency counter	Frequency counter that can count up to 20 MHz frequency (12 digits/s resolution)	53220A or 53230A

Voltage Standing Wave Ratio (VSWR) Performance Verification

VSWR is a measure of how efficiently an RF power is transmitted from an RF power source. In real systems, mismatched impedances between the RF source and load can cause some of the power to be reflected back towards the source and vary the VSWR.

This performance verification requires the following equipment.

- For low power S11 verification (-70 to +15 dBm):
 - PNA microwave network analyzer (N5225A)
 - N-Type calibration kit (85054D)
 - 3.5-mm calibration kit (85052B)
 - N-Type female adapter
 - 3.5-mm female adapter
- For high power S11 verification (+15 to +26 dBm):
 - PNA microwave network analyzer (N5225A with Option 217)
 - N-Type calibration kit (85054D)
 - 3.5-mm calibration kit (85052B)
 - N-Type female adapter
 - 3.5-mm female adapter
 - Power amplifier
 - Coupler (5087-7760 / 5087-7793)
 - Fixed attenuators (8490D)
 - Power meter (N1913A/N1914A)
 - Power sensor (N8481H/N8485A with Option 033)

Procedure

Low power S11 verification (without amplifier)

- 1 Set up the equipment as shown below. The network analyzer is used to perform the final return loss test.




Figure 2-1 Equipment setup for low power S11 verification

- 2 Set the start frequency of the network analyzer to 50 MHz and the stop frequency to 6 GHz (for the U2041/42XA), 18 GHz (for the U2043/44XA), and 33 GHz (for the U2049XA).
- 3 Set additional configuration on the network analyzer as follows:
 - IF bandwidth: 1 kHz
 - Power level: 0 dBm
- 4 Perform calibration for the 1-port return loss measurement using the appropriate calibration kit for the device type of the network analyzer (85054D for the U2041/42/43/44XA and 85052B for the U2049XA). Perform the calibration using the open, short, and load circuits / sliding load of the network analyzer.
- 5 After calibration, connect the U2040 X-Series to the test port of the network analyzer. Turn on **Correction** on the network analyzer to perform the VSWR measurement.

- 6 Connect the U2040 X-Series (device-under-test) to the 1-Port of the network analyzer and start the measurement for S11, SWR, and phase across frequencies.
- 7 Compare the measured results to the specifications in the table below. If the verification fails, return the U2040 X-Series to Keysight.

Table 2-2 Maximum SWR specifications (for low power S11 verification)

Frequency band	Maximum SWR	
	U2041XA/42XA	U2043XA/44XA
	-70 to +15 dBm	
10 MHz to 6 GHz	<1.2	<1.20
>6 GHz to 18 GHz	–	<1.26

Frequency band	Maximum SWR
	U2049XA
	-70 to +15 dBm
10 MHz to 30 MHz	<2.18
>30 MHz to 50 MHz	<1.35
>50 MHz to 100 MHz	<1.22
>100 MHz to 11.5 GHz	<1.17
>11.5 GHz to 30 GHz	<1.29
>30 GHz to 33 GHz	<1.33

High power S11 verification (with amplifier)

- 1 Set up the equipment as shown below.




Figure 2-2 Equipment setup for high power S11 verification

- 2 Turn off the amplifier.
- 3 Preset the network analyzer.

- 4 Configure the frequency range for the sensor model to be tested.
- 5 Set the **R1 Input Path** to **External : flow through R1 loop..**
- 6 Set the power level to -30 dBm or lower depending on the gain and output power of the amplifier.
- 7 Turn on the amplifier.
- 8 Set the **IF Band width** of the network analyzer to 1 kHz.
- 9 Perform a **Source Power Calibration** on the network analyzer:
 - a Connect the power meter with the U2040 X-Series to the network analyzer via a GPIB controller.
 - b Set the **Power Offset** to achieve the desired **Cal Power**.
 - c Select **Take Cal Sweep**.
 - d Follow the instructions on the display screen.
- 10 Perform calibration for the 1-port return loss measurement using the appropriate calibration kit for the device type of the network analyzer (85054D for the U2041/42/43/44XA and 85052B for the U2049XA). Perform the calibration using the open, short, and load circuits / sliding load of the network analyzer.
- 11 Ensure that the **"C 1-Port"** and **"SrcPwrCal"** status indicators are displayed on the network analyzer.
- 12 Connect the U2040 X-Series (device-under-test) to the test port of the network analyzer.
- 13 Compare the measured results to the specifications in [Table 2-3](#) on the next page. If the verification fails, return the U2040 X-Series to Keysight.

Table 2-3 Maximum SWR specifications (for high power S11 verification)

Frequency band	Maximum SWR	
	U2041XA/42XA	U2043XA/44XA
	+15 to +26 dBm	
10 MHz to 6 GHz	<1.29	<1.29
>6 GHz to 18 GHz	–	<1.30

Frequency band	Maximum SWR
	U2049XA
	+15 to +20 dBm
10 MHz to 30 MHz	<2.21
>30 MHz to 50 MHz	<1.37
>50 MHz to 100 MHz	<1.24
>100 MHz to 11.5 GHz	<1.21
>11.5 GHz to 30 GHz	<1.33
>30 GHz to 33 GHz	<1.36

NOTE

- To protect the network analyzer receivers from being overloaded, configure the network analyzer to turn off power if its receiver is overloaded.
- Depending on the amplifier being used, the test port power might not be sufficient. In this case, a banded setup with different amplifiers covering different frequency ranges might be required.
- The high power setup can be verified by performing the calibration and measurement at low power level, and comparing the results to the data from the low power setup without the amplifier.
- Use the fixed attenuators to lower the power seen by the network analyzer receivers so that they are not in the compression region. The receiver A attenuator can also be used to protect receiver A.
- For further information, refer to the Keysight's application note: *Recommendations for Testing High-Power Amplifiers Using the PNA Microwave Network Analyzers, 5989-1349EN.*

Sensor Accuracy Performance Verification

The purpose of this verification is to verify the accuracy of the U2040 X-Series after a period of usage to ensure that the U2040 X-Series is still within its published specifications.

This performance verification requires the following equipment.

- For low power verification (-20 to +10 dBm):
 - PSG analog signal generator (E8257D, with Option 1EU)
 - Power sensor (N8481A/N8485A with Option 033) × 2
 - Power meter (N1912A/N1914A/E4417A)
 - Power splitter (11667A)
- For high power verification (>+10 to +26 dBm):
 - PSG analog signal generator (E8257D)
 - Power sensor (N8481A/N8485A with Option 033) × 2
 - Power meter (N1912A/N1914A/E4417A)
 - Power amplifier
 - Directional RF coupler
 - Low-pass filter (for reducing the high harmonic content of the test signal to approximately -30 dBc for the 2nd harmonics)

Procedure

Low power verification

NOTE

- The accuracy error measured in this verification includes a combination of errors for linearity, calibration factor, and temperature compensation.
- The maximum input power to the 11667A splitter is 0.5 W or +27 dBm.
- To set the sensor mode (Average/Normal mode), send the `SENS:DET:FUNC AVER|NORM` command.
- To set the sensor video bandwidth, send the `SENS:BAND:VID OFF|HIGH|MED|LOW` command.
- The hardware paths for the OFF and HIGH video bandwidth are identical, while the paths for the MED and LOW video bandwidths are identical. Verification for the sensor's Normal mode can be performed in the OFF and MED video bandwidth settings.

- 1 Connect the standard sensor (N8481A/N8485A) to the power meter's channel A and the incident sensor (N8481A/N8485A) to the power meter's channel B.
- 2 The equipment setup is as shown below.




Figure 2-3 Equipment setup for low power verification

- 3** Zero and calibrate the standard and incident sensors on channels A and B respectively.
- 4** Set the frequency of the signal generator to 50 MHz and the power level to 0 dBm. Turn on the RF output.
- 5** Set the frequency of the power meter's channels A and B to the same frequency as the signal generator.
- 6** Measure the standard power (P_{STD}) of channel A and the incident power (P_{INC1}) of channel B. Compute and record the power ratio (P_{ratio}) of these channels for the current frequency and power level, based on the following equation:

$$P_{ratio}(dB) = P_{STD} - P_{INC1}$$

- 7** Repeat steps 4 to 6 for other frequencies with the same power level.
- 8** Turn off the RF output of the signal generator.
- 9** Remove the standard sensor from the test port.
- 10** Replace it with the U2040 X-Series, which is the device-under-test (DUT).
- 11** Zero and calibrate the DUT.
- 12** Measure and record the power readings for the current frequency and power level, as P_{DUT} (from the PC) and P_{INC2} (from the power meter's channel B).
- 13** Turn off the RF output of the signal generator.
- 14** Compute the accuracy error of the DUT for each frequency being measured at the same power level, using the following equations:

$$Accuracy\ error\ (dB) = P_{DUT} - (P_{INC2} + (P_{STD} - P_{INC1}))$$

$$Accuracy\ error\ (\%) = 100 \times \left[\text{antilog} \left[\frac{P_{DUT} - (P_{INC2} + (P_{STD} - P_{INC1}))}{10} \right] - 1 \right]$$

- 15** Repeat steps 12 to 14 for other frequencies with the same power level.
- 16** Compare the computed accuracy errors to the calibration uncertainty values in [Table 2-4](#) on [page 27](#). If the verification fails, return the U2040 X-Series to Keysight.

- 17 Repeat steps 4 to 16 by sweeping through the power levels from –20 dBm to +10 dBm. Level the power manually if necessary with reference to the incident sensor, using the following equation:

$$\text{Test port power} = P_{INC2} + (P_{STD} - P_{INC1})$$

Table 2-4 Calibration uncertainty specifications

Frequency band	Average mode		
	U2041XA/42XA	U2043XA/44XA	U2049XA
10 MHz to 30 MHz	4.4%	4.4%	4.5%
>30 MHz to 500 MHz	3.7%	3.7%	3.9%
>500 MHz to 1 GHz	3.7%	3.7%	3.8%
>1 GHz to 6 GHz	3.7%	3.7%	3.9%
>6 GHz to 10 GHz	–	3.7%	4.0%
>10 GHz to 18 GHz	–	4.0%	4.2%
>18 GHz to 26.5 GHz	–	–	4.9%
>26.5 GHz to 33 GHz	–	–	5.6%

Frequency band	Normal mode					
	Video band width OFF/HIGH			Video band width MED/LOW		
	U2041XA/42XA	U2043XA/44XA	U2049XA	U2041XA/42XA	U2043XA/44XA	U2049XA
10 MHz to 30 MHz	5.7%	5.7%	4.5%	4.4%	4.4%	4.5%
>30 MHz to 500 MHz	5.2%	5.2%	4.1%	3.7%	3.7%	3.9%
>500 MHz to 1 GHz	5.2%	5.2%	3.9%	3.7%	3.7%	3.9%
>1 GHz to 6 GHz	5.3%	5.3%	4.0%	3.7%	3.7%	4.0%
>6 GHz to 10 GHz	–	5.3%	4.1%	–	3.7%	4.1%
>10 GHz to 18 GHz	–	5.4%	4.3%	–	4.0%	4.2%
>18 GHz to 26.5 GHz	–	–	5.0%	–	–	4.9%
>26.5 GHz to 33 GHz	–	–	5.7%	–	–	5.6%

High power verification

NOTE

- The accuracy error measured in this verification includes a combination of errors for linearity, calibration factor, and temperature compensation.
- The maximum power for the U2049XA is +20 dBm.
- The frequency range of the DUT may be wider than the coupler selected in the test. More than one coupler may be required to cover the frequency range of the DUT.
- The procedure below is only applicable for limited verification. For full verification, you need to return the U2040 X-Series to Keysight.

- 1 Connect the standard sensor (N8481A/N8485A) to the power meter's channel A and the incident sensor (N8481A/N8485A) to the power meter's channel B.
- 2 The equipment setup is as shown below:




Figure 2-4 Equipment setup for high power verification

- 3** Offset the signal generator's power by the gain of the power amplifier. On the signal generator, press **Amplitude > More (1 of 2) > Ampl Offset**. Gain is entered as a positive number while loss is entered as negative number.

For example, if the amplifier gain is 28 dB, enter **+28** as the amplitude offset.

- 4** Zero and calibrate the standard and incident sensors on channels A and B respectively.
- 5** Set the frequency of the signal generator to 50 MHz and the power level to +10 dBm. Turn on the RF output.
- 6** Set the frequency of the power meter's channels A and B to the same frequency as the signal source.
- 7** Measure the standard power (P_{STD}) of channel A and the incident power (P_{INC1}) of channel B. Compute and record the coupling factor (P_{cpl}) of these channels for the current frequency, based on the following equation:

$$P_{cpl}(dB) = P_{STD} - P_{INC1}$$

- 8** Repeat steps 4 to 6 for other frequencies with the same power level.
- 9** Turn off the RF output of the signal generator.
- 10** Remove the standard sensor from the test port.
- 11** Replace it with the U2040 X-Series, which is the device-under-test (DUT).
- 12** Zero and calibrate the DUT.
- 13** Measure and record the power readings of channels A and B for the current frequency and power level, as P_{DUT} (from the PC) and P_{INC2} (from the N1912A's channel B).
- 14** Turn off the RF output of the signal generator.
- 15** Compute the accuracy error of the DUT for each frequency being measured at the same power level, using the following equations:

$$Accuracy\ error\ (dB) = P_{DUT} - (P_{INC2} + P_{cpl})$$

$$Accuracy\ error\ (\%) = 100 \times \left[\text{antilog} \left[\frac{P_{DUT} - (P_{INC2} + P_{cpl})}{10} \right] - 1 \right]$$

- 16** Repeat steps 13 to 15 for other frequencies with the same power level.

- 17** Compare the computed accuracy errors to the calibration uncertainty values in [Table 2-4](#) on [page 27](#). If the verification fails, return the U2040 X-Series to Keysight.
- 18** Repeat steps 13 to 17 by sweeping through the power levels from +10 dBm to +26 dBm. Level the power manually if necessary with reference to the incident sensor, using the following equation:

$$\text{Test port power} = P_{INC2} + P_{cpl}$$

Zero Set Performance Verification

The zero set verification is required to verify the zero level of the U2040 X-Series (DUT) after performing zeroing. This verification uses the 20 x 20 method, where the DUT is zeroed for 20 times and for each zero 20 free-run measurements are made, and the mean is obtained. The estimate of the zero level is the mean of the 20 set of mean measurements. The uncertainty of the measurement is stated as the 2x standard deviation of the mean values. The 2x standard deviation can be considered a guard band against the product specification.

System specifications:

Table 2-5 Zero set specifications

Mode	Video band width setting	Zero set	
		External zero	Internal zero
Normal	LOW/MED	<16 nW	<23 nW
	HIGH/OFF	<50 nW	<60 nW
Average	–	100 pW for <300 MHz	1 nW
		70 pW for \geq 300 MHz	

Equipment setup diagram




Figure 2-5 Equipment setup for zero set verification

Test equipment settings

Equipment	Key setting
U2040 X-Series	Free-run mode
	Auto-averaging enabled

SCPI commands

[Repeat for all frequency test points:]

U2040 X-Series commands

SENS:FREQ 50E6/1E9

INIT:CONT ON

UNIT:POW W

For external or internal zeroing:

CAL:ZERO:TYPE EXT/INT

Set the sensor mode (Average/Normal):

SENS:DET:FUNC AVER|NORM

Set the video bandwidth:

BAND:VID OFF|HIGH|MED|LOW

[Repeat for 20 times:]

CAL:ZERO:AUTO ONCE

[Repeat for 20 times:]

INIT

FETC?

For each 20 **FETC?** measurements, calculate the mean. Then calculate the standard deviation of the 20 means. Zero set is calculated as the mean of the 20 means. The uncertainty is reported as the 2x standard deviation of the 20 means.

Procedure

- 1** Send the commands as provided on [page 32](#).
- 2** Calculate the zero set for the different modes and conditions.
- 3** Compare the calculated values to the system specifications. If the verification fails, return the U2040 X-Series to Keysight.

10 MHz Timebase Accuracy Performance Verification

The 10 MHz timebase accuracy verification is required to verify the accuracy of time-based measurements made with the U2040 X-Series.

This performance verification requires a frequency counter (53220A).

System specifications: Timebase accuracy = ± 25 ppm

Equipment setup diagram




Figure 2-6 Equipment setup for 10 MHz timebase accuracy verification

Test equipment settings

Equipment	Key setting
U2040 X-Series	Auto-zeroing disabled
	Auto-calibration disabled
53220A frequency counter	50 Ω input impedance

U2040 X-Series commands

SYST:PRES

SERV:BIST:TBAS:STAT ON

CAL:ZERO:AUTO OFF

CAL:AUTO OFF

53220A commands

*RST

*CLS

*CAL?

INPUT1:IMP 50

INIT

FETC?

Procedure

- 1 Send the commands as provided above. The frequency from the 53220A must be within $10 \text{ MHz} \pm 250 \text{ Hz}$.
- 2 Compare the test values to the system specifications. If the verification fails, return the U2040 X-Series to Keysight.

Rise Time Performance Verification

NOTE

This verification is only applicable for the U2042XA, U2044XA, and U2049XA models.

Rise time verification is required to verify the system rise time of the analog measurement path, from the bulkhead to the inputs of the analog-to-digital converter (ADC). A pulse generator is used to modulate an RF signal generator with fast rise time, and this is captured by the ADC. An equivalent time sampling method is used to calculate the rise time of the captured trace.

This performance verification requires the following equipment:

- Function generator (33250A/33220A)
- Signal generator (N5172B)

System specifications:

Rise/fall time: ≤ 100 nsecs (with the video bandwidth turned off, the measured signal frequency is ≥ 300 MHz)

Equipment setup diagram




Figure 2-7 Equipment setup for rise time verification

Test equipment settings

Equipment	Key setting
N5172B signal generator	IQ modulation: ON
	RF: ON,
	Mod: ON
33250A/33220A function generator	Pulse waveform
U2042XA/U2044XA/U2049XA (DUT)	Trace mode, undecimated
	Trace length: <1.2 ms

U2042XA/U2044XA/U2049XA SCPI commands

To configure measurement settings:

```

SYST:PRES
SENS:DET:FUNC NORM
INIT:CONT OFF
SENS:AVER OFF
SENS:AVER2 OFF
CAL:ZERO:AUTO OFF
CAL:AUTO OFF
SERV:BIST:TBAS:STAT ON
SENS:FREQ 1e9
TRIG:SOUR EXT
TRAC:STAT ON
TRAC:UNIT W
SENS:TRAC:TIME 500e-6
SENS:BAND:VID LOW|MED|HIGH|OFF

```

To trigger measurement readings:

INIT

FETC?

TRAC:DATA? HRES

33250A/33220A function generator settings

- Pulse waveform
- Period: 99.99 μ s
- HiLevel: 500 mV
- LoLevel: 0 mV
- Pulse width: 50 μ s
- Edge time: 20 ns

N5172B signal generator settings

- Frequency: 1 GHz
- Power: +10 dBm
- IQ modulation: ON
- RF: ON
- Mod: ON

MATLAB code (*calculate the rise time of the captured trace using the equivalent time sampling method*)

```

L=2000;
D=5;

aves=1;

data=A;
eff_data_hi=zeros(L*D,1);

    for i=0:aves-1 % averaging loop
        n=0;
        for j=1:L %
            for k=1:D
                n=n+1;
                m=j + (k-1)*L
                eff_data_hi(n)=eff_data_hi(n)+data(m);
            end
        end
    end
    %disp('finished')
    eff_data_hi=eff_data_hi/aves;
    X=eff_data_hi

```

The pulse top and pulse bottom are determined by constructing a histogram on the captured trace.

The rise time is measured as the time from 10% above the pulse bottom and 90% above the pulse bottom.

Procedure

- 1 Send the commands as provided on [page 37](#).
- 2 Process the trace capture using the MATLAB code as provided on [page 39](#).
- 3 Locate the pulse top and pulse bottom. Calculate the rise time from 10% to 90%.

$$Rise\ time_{measured} = \sqrt{Rise\ time_{DUT}^2 + Rise\ time_{system}^2}$$

Thus,

$$Rise\ time_{DUT} = \sqrt{Rise\ time_{measured}^2 - Rise\ time_{system}^2}$$

- 4 Compare the calculated values to the system specifications. If the verification fails, return the U2040 X-Series to Keysight.

3 Repair Guide

Troubleshooting	42
Repair	42

This chapter contains information on troubleshooting and repair of the U2040 X-Series.

Troubleshooting

The U2040 X-Series represents a combination of a power meter and a power sensor in one unit. If the LED is red and blinking, it indicates that there is a hardware error or operating system (OS) error in the U2040 X-Series. The LED will only blink red if the U2040 X-Series encounters any system error. The **SYSTem:ERRor?** query is used to read the exact error messages of the errors that occur on the U2040 X-Series. You should send the U2040 X-Series to the nearest Keysight Service Center for repair. Refer to the *User's Guide* for more information on the LED indicators.

CAUTION

Electrostatic discharge will render the U2040 X-Series inoperative. Do not, under any circumstances, open up the U2040 X-Series unless you and the U2040 X-Series are in a static-free environment.

Repair

There are no serviceable parts inside the U2040 X-Series. If the U2040 X-Series is defective, send it back to the nearest Keysight Service Center for repair.

4 Contacting Keysight

Introduction	44
Returning the U2040 X-Series for Service	46

This chapter explains the appropriate actions to take if you have a problem with your U2040 X-Series.

Introduction

This section provides the information on what to do if you encounter problems with your U2040 X-Series.

If you wish to contact Keysight to enquire about the U2040 X-Series, from service problems to ordering information, refer to [“Sales and Technical Support”](#) on page 5.

If you wish to return the U2040 X-Series to Keysight, refer to [“Returning the U2040 X-Series for Service”](#) on page 46.

Instrument serial number

Keysight makes frequent improvements to its products to enhance their performance, usability, and reliability. Keysight service personnel have access to complete records of design changes for each instrument. The information is based on the serial number and option designation of each U2040 X-Series.

Whenever you contact Keysight about your U2040 X-Series, have a complete serial number available. This ensures you obtain the most complete and accurate service information. The serial number can be obtained from the serial number label.

The serial number label is attached to the side panel of the U2040 X-Series. This label has two instrument identification entries. The first provides the instrument serial number and the second provides the identification number for each option built into the instrument.

The serial number is divided into two parts: the prefix (two letters and the first four numbers), and the suffix (the last four numbers).

- The prefix letters indicate the country of manufacture. This code is based on the ISO international country code standard, and is used to designate the specific country of manufacture for the individual product. The same product number could be manufactured in two different countries. In this case, the individual product serial numbers would reflect different country of manufacture codes. The prefix also consists of four numbers. This is a code identifying the date of the last major design change.
- The suffix indicates an alphanumeric code which is used to ensure unique identification of each product throughout Keysight.




Figure 4-1 Serial number

Recommended calibration interval

Keysight recommends a 1-year calibration cycle for the U2040 X-Series.

Returning the U2040 X-Series for Service

Use the information in this section if you need to return your U2040 X-Series to Keysight.

Packaging the U2040 X-Series for shipment

Use the following procedure to package the U2040 X-Series for shipment to Keysight for servicing:

- Be as specific as possible about the nature of the problem. Send a copy of any information on the performance of the U2040 X-Series.

CAUTION

Damage to the instrument can result from using packaging material other than those specified. Never use styrene pellets in any shape as packaging material. They do not adequately cushion the instrument nor prevent it from shifting in the carton. Styrene pellets cause instrument damage by generating static electricity and by getting lodged in the instrument panels.

- Use the original packaging material or a strong shipping container made of double-walled, corrugated cardboard with 91 kg (200 lb.) bursting strength. The carton must be large and strong enough to accommodate the U2040 X-Series and allow at least 3 to 4 inches on all sides of the U2040 X-Series for packing material.
- Surround the U2040 X-Series with at least 3 to 4 inches of packing material, or enough to prevent the U2040 X-Series from moving in the carton. If packing foam is not available, the best alternative is SD-240 Air Cap from Sealed Air Corporation (Commerce, CA 90001). Air Cap looks like a plastic sheet covered with 1-1/4-inch air-filled bubbles. Use the pink Air Cap to reduce static electricity. Wrap the U2040 X-Series several times in the material as protection and to prevent it from moving in the carton.
- Seal the shipping container securely with strong nylon adhesive tape.
- Mark the shipping container as “FRAGILE, HANDLE WITH CARE” to ensure careful handling.
- Retain copies of all shipping papers.



This information is subject to change without notice. Always refer to the English version at the Keysight website for the latest revision.

© Keysight Technologies 2016
Edition 1, April 01, 2016

Printed in Malaysia



U2041-90004

www.keysight.com